

# ORTF-2plus2 WINDSHIELD WITH FUR OR RAIN COVER

## SETUP GUIDE



# CONTENTS

1. REMOVING THE TRANSPORT LOCK.....	3
2. ORIENTATION OF THE WINDSHIELD .....	4
3. CHANNEL ALLOCATION.....	4
4. RAIN COVER OR FUR* .....	5

## 1. REMOVING THE TRANSPORT LOCK

The ORTF-2plus2 windshield is often shipped with a foam ball transport lock ("Transportschutz") installed, as this prevents damage in (long overseas) shipping in which the elastic suspensions may be overly stressed.

**The transport lock must be removed before use!**



Windshield without black fabric cover  
**with transport lock**



Open windshield without black fabric cover  
**without transport lock**

How to remove the transport lock:

- a) Remove fur\* if installed.
- b) Remove the black fabric cover.
- c) Open the lid.
- d) Carefully remove the spherical foam balls and other foam parts.
- e) Close the lid.
- f) Reinstall the black fabric cover.
- g) Reinstall fur\* if desired.

## 2. ORIENTATION OF THE WINDSHIELD

The *left side of the setup* is marked by a label (LEFT CINELA) on the black fabric and on the fur (SCHOEPS ORTF-2plus2). Orient the windshield according to this label.



## 3. CHANNEL ALLOCATIONS

The following table shows the channel allocations:



### CHANNEL ALLOCATIONS OF THE ORTF-2plus2 SETUP

Channel #	Labeling on the cable outlet and the Multi-core breakout cable	Channel routing
1	Ch 1 (L) – Yellow	L
2	Ch 2 (R) – Red	R
3	Ch 3 (Ls) – Blue	LSh
4	Ch 4 (Rs) – Green	RSh

## 4. RAIN COVER OR FUR\*

The windshield can be used with the black fabric cover alone, or with either fur\* (for heavy wind) or the rain cover (for rain) as a second layer. Don't install both the fur\* and rain cover at the same time.

The installation is very easy:



Windshield with Rain Cover  
(close velcros for use)



Windshield with Fur  
(close buttons for use)

\*fake fur